



OPERATIONS *GUIDE*

MARK IV TANK FLOOR SCANNER



- ***LIGHTWEIGHT***
- ***RUGGED***
- ***RELIABLE***



CONTACT US :

150 Holder Lane
Dripping Springs, TX, 78620
Web: www.mfeenterprises.com
Phone: (281) 441-8284

MARK IV TANK FLOOR SCANNER



THE MARK IV TANK FLOOR SCANNER OPERATIONS GUIDE

SAFETY NOTICE

This equipment makes use of very powerful rare earth magnets. Great care should be exercised when disassembling the unit or moving the magnetic bridge to prevent damage to either the operator or equipment.

This equipment should only be handled and operated by personnel who have received the necessary training from MFE ENTERPRISES, INC. Should it be necessary to unpack the transportation case prior to any training, please note that this equipment uses **very powerful magnets** that can be hazardous if mishandled and the equipment itself can be damaged. The magnetic bridge is mounted to a keeper plate in the transportation case for shipping purposes and should not be disturbed prior to the arrival of the MFE-trained personnel.

It is strongly recommended to fully charge the unit prior to use.
Do not use any battery chargers other than the ones provided to charge this equipment.



CHECKLIST

- ① Remove Handle Assembly from case.
- ② Attach Handle Assembly to Bridge Assembly (with bridge on keeper plate).
- ③ Attach all 3 cables.
- ④ Adjust Sensor Bar to the #1 Setting.
- ⑤ Press Power Button to Turn On Scanner (should automatically boot into Mark 4 Software).
- ⑥ Select Manual Tab in software.
- ⑦ Select Configuration Screen and adjust plate thickness to 1/2" and coating thickness to 0 (Keeper plate is 1/2" thick and requires this change to perform function test).
- ⑧ Scan Keeper Plate to verify that you receive a signal response on all 12 channels.
- ⑨ Select Configuration Screen and adjust plate/coating thickness to match conditions of tank floor.
- ⑩ Adjust Sensor Bar to the #3 Setting.
- ⑪ Remove scanner from keeper plate and place scanner on tank floor.
- ⑫ Adjust Sensor Bar to the lowest setting possible without it scraping the tank floor on a consistent basis.

SCANNER IS READY TO BEGIN TANK FLOOR INSPECTION!


MARK IV TANK FLOOR SCANNER

INTRODUCTION

The content of the Mark IV Tank Floor Scanner Operations Guide is intended to provide guidance during setup, assembly, and to familiarize operators with the various parts of the Mark IV. **It is not a substitute for the Mark IV Training Course that is necessary for the proper use of the MFE Mark IV Tank Floor Scanner.**

The Mark IV uses Magnetic Flux Leakage as a detection tool. The powerful magnetic bridge allows for saturation of the inspected material. Any localized reduction in the thickness of the inspected material will result in a flux leakage at the surface. A series of sensors are placed between the poles of the magnetic bridge to detect these leakage fields. The strength of the leakage field is a function of volume loss and is not a reliable indication of remaining wall thickness. Although the amplitude of the signal generated by the sensors gives some relative severity information, it is not recommended that amplitude alone be used for accept/reject criteria purposes. Flux leakage should only be used as a detection tool. Quantitative information can only be obtained using ultrasonic assessment of the areas identified by the magnetic flux leakage scanner.

MARK IV DIAGRAM



CASE CONTENTS



LARGE CASE WITH HANDLE ASSEMBLY

EQUIPMENT ID NUMBER

Each case exterior displays the ID number of the equipment it carries.



Before removing the Mark IV Handle Assembly from the case, remove the battery charger and foam insert. Remember the location of these items as they will be needed to properly repackage the equipment.

EXTRA BATTERIES


HANDLE ASSEMBLY

OPERATION GUIDES & USB DRIVE

AC ADAPTER & BATTERY CHARGER POWERCORD

BATTERY CHARGER

ELECTRONICS, ENCODER AND SIGNAL CABLE STORAGE



SPACE AVAILABLE FOR
ADDITIONAL BATTERY STORAGE

CASE CONTENTS



LARGE CASE WITH HANDLE ASSEMBLY

GETAC TABLET
REFERENCE GUIDE

GETAC BATTERY PACK
USER GUIDE



EXTRA BATTERY #1



EXTRA BATTERY #2



MARK IV TANK SCANNER
OPERATIONS GUIDE



MICROFIBER SCREEN
CLEANING CLOTH



TOUCHSCREEN COMPATIBLE GLOVES



GETAC BATTERY CHARGER
OPERATION GUIDE

BATTERY CHARGER




USB DRIVE



AC ADAPTER



REMOVABLE FOAM INSERT



ENCODER
CABLE



SIGNAL CABLE



ELECTRONICS CABLE



CASE CONTENTS & ASSEMBLY




SMALL CASE CONTAINING BRIDGE

MAGNETIC BRIDGE

SENSOR BAR ADJUSTMENT BRACKET

Adjust the sensor bar by pushing down on bracket, turn both knobs so they are at equal positions, then release bracket.

SENSOR BAR




EQUIPMENT ID NUMBER

The large and small cases have matching ID numbers that coincide with the equipment ID of the enclosed Mark IV Tank Floor Scanner.

ENCODER

KEEPER PLATE

The keeper plate serves a dual purpose of containing the magnetic field for shipment purposes and function testing the equipment using a series of side-by-side defects.



QUICK-RELEASE PINS ATTACH THE HANDLE BAR ASSEMBLY TO THE BRIDGE ASSEMBLY



Attach the handle to the bridge by adjusting the lever to the correct position and allow the quick-release pins to lock into place.

When ready to **detach** the handle, gently raise the top of the handle while rotating the levers 180 degrees.




HANDLE ASSEMBLY

PARTS & CABLE SETUP



Turn lever counterclockwise to unlock tablet holder. Set tablet at desired angle and turn lever clockwise to lock tablet into place.

RECEPTACLE FOR SENSOR CABLE & ENCODER CABLE




MAGNETIC BRIDGE TO HANDLE ASSEMBLY CABLE CONNECTIONS

Connect the signal cable and the encoder cable from bridge to handle by lining up the red dots on the cables and receptacles.

Since the sensor bar is not visible from the top, the cable can be gently pressed in to the receptable and slowly rotated until the proper alignment is discovered.

POWERING THE TABLET & MARK IV



POWER BUTTON

The green power button is used to turn the power to the tablet (and tank floor scanner) on and off.

Once powered on, the Mark IV Scanner Software will automatically boot up as your home screen. In the event that the software fails to boot up, then press the green button to power off the tablet and then turn the power back on.

Powering up the software may take 1-2 minutes.

HOT SWAPPABLE BATTERIES



The tablet batteries power both the GETAC tablet as well as the entire Mark IV Tank Floor Scanner. Operators are able to replace one battery at a time with no power interruption to the Mark IV.


When replacing the batteries, insert the side opposite of the clear tab first and push in the interior side adjacent to the yellow tabs second. When inserted the clear tabs on each battery will be on the same side as the yellow tabs.

Pressing the power buttons located directly on each battery will light up a battery power indicator.

For additional details on the tablet, please refer to the GETAC F110 Operation Guide included with the scanner or go to <http://us.getac.com/tablets/F110/specs.html>.



MANUAL MODE



- 1 Displays current mode of operation: Manual or Mapping.
- 2 Plate and Coating Configuration – Options for changing the settings for different plate and coating thickness (Image 5).
- 3 General Settings – Select between Imperial and Metric (Image 6).
- 4 **Speed Meter:** Displays speed at which scanner is moving. All signals generated inside the green zone are speed-corrected; signals generated outside the green zone are not.
- 5 **Alarm Threshold:** Active when the alarm is on. Slide the bar to the desired position. Once the signal reaches this level, the alarm will trigger with a red screen (See Image 2).
- 6 Displays measurement system currently selected in the configuration screen: imperial or metric.
- 7 C-Scan Type Image – Overhead display of signals used to easily located defects. Move your thumb and pointer finger away from each other to zoom in, and "pinch" them together to zoom out (Image 5).
- 8 12 Channel Real Time Display (RTD) – 12 Channel display of the MFL signals generated by the scanner.
- 9 **Alarm Enable / Disable:** Click to enable/disable Alarm Mode. The alarm is triggered once the signal reaches the threshold level(Image 3). In the even that the threshold is set too low and the alarm constantly triggers when reset, swap mapping mode and back to manual mode.
- 10 Battery Level – Current level of the GETAC F110 batteries.

MANUAL MODE

IMAGE 2 - ALARM TRIGGERED






IMAGE 3 - ALARM ENABLED



MANUAL MODE

IMAGE 4 (ZOOMED IN ON OVERHEAD SCAN)



DEFECT SIGNALS


MANUAL MODE

IMAGE 5 (PLATE AND COATING SETTINGS)




- 1 **SELECT PLATE THICKNESS:** Selecting the plate will adjust the signal accordingly.
- 2 **COATING THICKNESS:** Selecting the thickness of coating will adjust the signal accordingly.
- 3 **SIGNAL:** For advanced users. Signal is adjusted by coating and plate thickness selection. Operator can change signal for less or more signal strength. The lower the mV number, the more signal strength. The higher the number, the less signal strength.

IMAGE 6 (SETTINGS)



MAPPING MODE

HOME SCREEN



- 1 Select 'Import Tank' to import a previously saved tank from a USB Drive.
- 2 Choose the 'Select Tank' option to go to a menu that lists your previous tanks.
- 3 Selecting 'Create New Tank' takes you to the take creation screen before scanning a new tank.

MAPPING MODE


TANK CREATION SCREEN

The screenshot shows the 'Create New Tank' screen in 'MAPPING MODE'. The interface includes a top bar with 'MANUAL MODE' and 'MAPPING MODE' tabs, and a title 'MFE Mark IV'. The main area features a central circular tank diagram with 28 numbered segments. To the left of the diagram are input fields for 'Tank Name' (Test Tank #1), 'Tank Diameter' (100 ft), 'Number of rows in tank' (7), 'Number of annular plates' (0), 'Angle Offset' (0°), and 'Edge Width of Annular Plates' (0 in). To the right is a 'Number of plates per row' section with a grid for Row 1 to Row 4. At the bottom left is a 'CANCEL' button and at the bottom right is a 'FINISH' button. Red circles with numbers 1 through 7 are overlaid on the screen to indicate the sequence of steps for creating a tank.

- 1 **TANK NAME and DIAMETER:** Enter a name and the diameter of your tank.
- 2 **NUMBER OF ROWS IN TANK:** Use the plus and minus buttons to input your rows or directly input them using the virtual keyboard.
- 3 **NUMBER OF ANNULAR PLATES & ANGLE OFFSET:** Enter the number of annular plates around your tank. 'Angle Offset' allows the operator to shift the angle of the tank diagram to better reflect the tank being scanned.
- 4 **EDGE WIDTH OF ANNULAR PLATES:** Enter the edge width of annular plates to adjust their appearance in the tank diagram.
- 5 **NUMBER OF PLATES PER ROW:** Enter the number of plates per row here. To access additional rows, swipe up or down on the row section of the screen.
- 6 **CANCEL:** Clicking the cancel button will take you to the home screen. By clicking cancel before finishing your tank, you will restart the tank creation process and your work will not be saved.
- 7 **FINISH:** When your tank details have been entered, click Finish to save your tank.

MAPPING MODE

PLATE SELECTION



- 1 **EDIT TANK:** The 'Edit Tank' option allows you to revert back to the 'Tank Creation Screen' to make adjustments to your tank details.
- 2 **CHANGE TANK:** Select this option to switch to a previously created tank file.
- 3 **EXPORT TANK:** Select 'Export Tank' to save your tank to a USB drive. **This feature will be used to export the final inspection report.**
- 4 **PLATE SELECTION USING DIAGRAM:** Touch the plate within the tank diagram on the screen you would like to scan.
- 5 **SELECT PLATE:** You may also enter the plate number that corresponds with the plate you are going to scan here by using the virtual keyboard.
- 6 **PLATE SETUP:** When you have completed creating your tank and are ready to begin scanning your first plate, choose 'Plate Setup.' **Once Plate Setup is selected and you begin scanning, you will not be able to make changes to your tank diagram.**

MAPPING MODE

PLATE DIMENSIONS

MANUAL MODE **MAPPING MODE** MFE Mark IV

Plate 1 **DIMENSIONS** THICKNESS CORNER & OFFSET DIRECTION TASK OVERVIEW

Set plate dimensions

Length [ft] 20 Width [ft] 12

2 NEXT

RTD Software Version Default Signal Range: 0mV - 1000mV Units: Imperial Mode: Mapping BATTERY

- 1 Enter the length and width of your plate on this screen.
- 2 Click NEXT to move onto the next screen.

COATING THICKNESS

MANUAL MODE **MAPPING MODE** MFE Mark IV

Plate 1 DIMENSIONS **THICKNESS** CORNER & OFFSET DIRECTION TASK OVERVIEW

Set plate thickness and signal range

1 Plate Thickness 1/4 in 3/8 in 1/2 in

2 Coating Thickness 0 125 250 375 500

3 Signal 0 mV 1000 mV


4 NEXT

RTD Software Version Default Signal Range: 0mV - 1000mV Units: Imperial Mode: Mapping BATTERY

- 1 Select your plate thickness here.
- 2 Enter coating thickness here.
- 3 Selecting plate thickness and coating thickness will determine a preset signal range. This range can be manually adjusted here.
- 4 Click NEXT to move onto the next screen.


MAPPING MODE

CORNER & OFFSET



- 1 You may offset the location of the bridge by entering its specific location on the X and Y axis of the plate here.
- 2 Select your reference corner on the plate by touching BL (Bottom Left), BR (Bottom Right), TL (Top Left), or TR (Top Right).
- 3 Click NEXT to move onto the next screen.


SCANNING DIRECTION



- 1 Select your scanning direction on the 'Direction' screen.
- 2 This is the final selection of the plate setup process. You may now select 'Scan' and begin scanning the plate.

MAPPING MODE

SCANNING A PLATE



- 1 SPEED TRACKING:** The scanner will begin recording when the speed reaches the green zone. It will automatically stop recording when the speed exits the green zone (too fast, too slow, or stops). Speed Compensation Software allows operators scanning at different speeds to obtain the same results. The signal response is normalized when scanning within the speed tracking range.
- 2 DISCARD TANK:** Select the discard button to discard your data and scan the plate again.
- 3 SAVE:** Select this option once you've completed scanning your plate to save the data.